



iKiss

How to assemble

Screw iKiss atomizer tube on the iKiss atomizer base and iKiss atomizer on iKiss power supply.



① iKiss Atomizer Tube ② iKiss Atomizer Head ③ iKiss Base ④ iKiss Power Supply

iKiss Atomizer

The cartridge of the iKiss and the atomizer is a one-piece. But the atomizer head is replaceable, this will be more convenient for you. It adopts the unique way of air inflow and the transparent atomizer tube, so that you can clearly know the state of the liquid.

How to charge

Plug the battery into its dedicated cable. Then plug the USB port into the wall adapter or other power source such as a computer. When it is charging, the indicator light will flash. When fully charged, the indicator light will go out.

How to add liquid

Unscrew iKiss base and refill it from the bottom of iKiss atomizer. Please do not fill iKiss tube too full, and you'd better have a little room to spare.

Precautions

- Have your iKiss repaired only by Eleaf. Do not repair the unit by yourself as damage or personal injury may occur.
- Do not leave iKiss in high temperature or damp condition, otherwise its performance may abate. The appropriate operation temperature is between 0 °C and 45 °C and the appropriate charging temperature between -10 °C and 60 °C.
- Do not assemble iKiss with non-Eleaf parts. Any problem caused by this will invalidate your warranty and our company will not take on any responsibility.

MADE IN CHINA
Manufactured by iSmoka

